

MANUFACTURER	ADAPTERS REQUIRED*
Audi	BA05
BMW/Mini	BA05
GM/Chevrolet/Cadillac/GMC/Buick/Pontiac	BA04 , BA05
Chrysler/Dodge/Ram/Jeep	BA01 , BA04 , BA05
Daewoo	BA04 , BA05
Ferrari	BA05
Fiat	BA05
Ford	BA02 , BA03 , BA04 , BA05
Honda	BAH1
Hyundai	BA03
Jaguar	BA05
Kia	BA03 , BA05
Lamborghini	BA05
Land Rover	BA05
Lexus	BA10
Maserati	BA05
Mazda	BA03 , BA04 , BA05
Mercedes-Benz	BA05
Mitsubishi	BA03
Nissan	BA03 , BA05 , BA13
Porsche	BA05
Renault	BA05
Rover	BA03
Saab	BA03
Subaru	BA03
Suzuki	BA03
Toyota	BA10 , BA05
Volvo	BA05
Volkswagen	BA05

*BA02R, BA03R & BA04R apply to same vehicles as the BA02, BA03 & BA04 adapters.



BAK8

**Brake Adapter Kit
8 Adapters
(Probe Style)**



BAK8R*

**Brake Adapter Kit
8 Adapters
(Probe & Ring Style)**

*BA02R, BA03R & BA04R
instead of probe style.

