

A/C Evaporator Core Cleaner is a pressurized foaming cleaner that's apply to the vehicle using the evaporator drainage tube. A/C Evaporator Core Cleaner helps remove debris, dirt, and mildew and leaves behind a fresh scent.

FEATURES AND BENEFITS:

- Cleans Evaporator Core
- Improves Cooling Efficiency
- Improves Air Quality
- Helps Eliminate Odors



SHAKE WELL BEFORE USE. DIRECTIONS: Please note: For all makes and models, refer to the owners manual to locate the evaporator/heater core and use general directions below.

DO NOT TURN ON FAN. Wear latex gloves, long sleeves, and eye protection prior to using this product. For best results, protect all electrical equipment and parts. Put vehicle on lift and locate drain tube from evaporator/heater housing. Shake can well and insert hose into drain tube. Spray entire contents of can into evaporator/heater housing. Once can is empty, remove hose from drain tube and immediately put a waste container under drain tube. Allow product to work for a minimum of 15 minutes. Then turn on vehicle fan on the lowest setting and run for at least 10 minutes and allow cleaner to completely clean and drain from evaporator/heater core and housing. The foam will drain back out the drain tube removing contaminates and odor.

CAUTION: Improper usage can cause damage. This product is not recommended for vehicles where the door or duct opening is located on the low side of the evaporator case and cannot be completely sealed watertight during the cleaning process. Any leakage can result in damage to adjacent electronics or equipment plus stain the carpet.

SPECIFICATIONS:

Product No.: M10521

Net Weight: 10oz (295.73mL)

Case Quantity: 12 each

